DART SERVICE INSTRUCTION

TO AMEND INSTALLATION INSTRUCTIONS D350-567 REV. D AND INSTRUCTIONS FOR CONTINUED AIRWORTHINESS ICA-D350-567 REV. 1

REF. TCCA STC: SH92-18

REF. FAA STC: SH989NE AND SH990NE

REF. EASA STC: EASA.IM.R.S.01560 AND EASA.IM.R.S.01561

1.0 PURPOSE

This service instruction is intended for customers wishing to upgrade their existing OEM small vertical reference window kit to a DART D350-567-111 Floor Window Kit. Since the DART D350-567-115 Floor Window Kit included with D350-567-111 does not share the same rivet patterns as the OEM kit, the D350-567-111B/-115B Kits from this service instruction replaces the D350-567-111/-115 Kits to facilitate installation without having to perform extensive rework/repair of the aircraft floor prior to installation.

2.0 INSTALLATION OF D350-567-111B:

Note: With reference to Installation Instructions D350-567, make the following substitutions:

- D3293-1B replaces D3293-1;
- D3294-1B replaces D3294-1;
- D3295-041B replaces D3295-041;
- D3296-041B replaces D3296-041.
- 2.1 Perform Step 3.3.1 of Installation Instructions D350-567 as required.
- 2.2 Locate the D3293-1B per Figure 1 of this service instruction.
- 2.3 Enlarge the viewing hole in the aircraft floor by using D3293-1B as template.
- 2.4 Transfer drill Ø0.128" holes from the aircraft floor to D3293-1B Doubler, D3294-1B Bracket, and D3295-041B Window. Drill additional holes as required through D3293-1B and aircraft floor. Ensure minimum pitch and edge distance as indicated.
- 2.5 Enlarge existing Ø0.128" holes to Ø0.141" as required and drill qty(4) Ø0.141" as shown in Figure 1 of this service instruction for a total of qty(9) Ø0.141" holes.
- 2.6 Locate D3296-041B and transfer drill qty(12) Ø0.128" and qty(3) Ø0.141" holes from the D3293-1B Doubler/aircraft floor to the blank hinge blade of D3296-041B.
- 2.7 Complete installation in accordance with Section 3.3 of Installation Instructions D350-567.
- 2.8 Touch up finish on drilled parts in accordance with Section 5.1.3 of ICA-D350-567.
- 2.9 Install the D350-567-113 Kit per Section 3.7 of D350-567. No changes.

CANADA
DEPARTMENT OF TRANSPORT
AIRCRAFT CERTIFICATION
BRANCH
DAO # 01-O-01

APPROVED

D. SHEPHER® (DE # 02)

DATE: 12.11.16
CERT. NO.: SH92-18
ISSUE NO.: 6

Α	NEW ISS	JE ,		МВ	12.11.15
REV.		1,	DESCRIPTION	BY	DATE
DESIGN		DART AE	DART AEROSPACE LTD		
DRAWN			HAWKESBURY, ONTARIO, CANADA		DA
CHECKE	D	W	DRAWING NO.		REV. A
MFG. APPR.		N/A	DSI 9637	· _ S	HEET 1 OF 4
APPROV	/ED	M	TITLE		SCALE
DE APPF	₹.	_#	INSTALL MOD		NTS
DATE 12.11.15		THIS DOCUMENT IS PRIVATE AND CONFIDENTS	COPYRIGHT © 2012 BY DART AEROSPACE LTD THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATIED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.		

3.0 PARTS LIST

QTY	QTY	QTY		
-111B	-113	-115B	Part Number	Description
Х			D350-567-111B	FLOOR WINDOW INSTALLATION, EXTRA
	·			LARGE (BLANK)
1	Х		D350-567-113	REPLACEMENT WINDOW KIT (EXTRA
				LARGE)
11		X	D350-567-115B	INTERIOR FLOOR WINDOW KIT (BLANK)
	1		D2463-0860	NEOPRENE SEAL
	4		D0000 044	REPLACEMENT WINDOW ASSEMBLY,
	1		D3290-041	EXTRA LARGE
	12		2600-6	1/4 TURN FASTENER
	12		2600-LW	WASHER
	12		212-12	RECEPTACLE
	21		AN526C832R9	SCREW (OR AN526C832-9, OR MS51957-126)
	42		AN960JD8	WASHER
	21		MS21042L08	NUT (OR MS21042-08)
	24		MS20426AD3-5	RIVET
	2 SQ. YD		N/A	9.7 OZ 7781 'S' GLASS UNIVERESAL WEAVE
		1	D3293-1B	DOUBLER, BLANK
		1	D3294-1B	BRACKET, BLANK
		1	D3295-041B	FLOOR WINDOW, BLANK
		1	D3296-041B	DOOR ASSEMBLY, W/BLANK HINGE BLADE
		1	D2463-0530	NEOPRENE SEAL
		9	AN526C632R12	SCREW (OR AN526C632-12, OR MS51957-32)
		9	AN960JD6	WASHER
		9	MS21042L06	NUT (OR MS21042-06)
		2	MS20470AD4-5	RIVET
		115	MS20470AD4-6	RIVET
		. 15	MS20470AD4-7	RIVET

4.0 WEIGHT AND BALANCE

For D350-567-111B, use the weight and balance information for D350-567-111...

5.0 MAINTENANCE AND CONTINUED AIRWORTHINESS

Maintenance and continued airworthiness instructions for D350-567-111B is the same as for D350-567-111. Refer to ICA-D350-567.

CANADA
DEPARTMENT OF TRANSPORT
AIRCRAFT CERTIFICATION
BRANCH
DAO # 01-0-01

APPEOVED

D. SHEPHERD (DE # 02)

DATE: 12.11.16

CERT. NO.: SH92-18

ISSUE NO.: 6

	A		·	
DESIGN	1	DART AEROSPACE LTD		
DRAWN .	<u>k</u>	HAWKESBURY, ONTARIO, CANADA		
CHECKED	41	DRAWING NO.	REV. A	
MFG. APPR.	N/A	DSI 9637	SHEET 2 OF 4	
APPROVED	\M.	TITLE	SCALE	
DE APPR.		INSTALL MOD	NTS	
DATE 12 1	1 15	COPYRIGHT © 2012 BY DA THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SU	IPPLIED ON THE EXPRESS CONDITION THAT IT IS	




FIGURE 1: D350-567-115B KIT OVERVIEW (SLIDING DOOR MOD NOT SHOWN)

CANADA
DEPARTMENT OF TRANSPORT
AIRCRAFT CERTIFICATION
BRANCH
DAO # 01-O-01

BY: D. SHEPHER® (DE # 02)

DATE: 12.11.16

CERT. NO.: SH92-18

ISSUE NO.: 6

DESIGN	[کے
DRAWN	
CHECKED	W
MFG. APPR.	NA
APPROVED	M.
DE APPR.	-##
DATE 12.1	1.15

DART A	EROSP	ACE	LTD
HAMMERD	HIDV ONTAR	DIO CAN	

DRAWING NO. REV. A

NTS

DSI 9637 SHEET 3 OF 4

TITLE SCALE

INSTALL MOD

COPYRIGHT © 2012 BY DART AEROSPACE LTD

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WITTEN PERMISSION FROM DART AEROSPACE LTD.

